



# Forwarding Configuration Guide

**Version 20.5.1-rc0, 25 May 2020**

Registered Address	Support	Sales
26, Kingston Terrace, Princeton, New Jersey 08540, United States		
		+91 80 4850 5445
<a href="http://www.rtbrick.com">http://www.rtbrick.com</a>	<a href="mailto:support@rtbrick.com">support@rtbrick.com</a>	<a href="mailto:sales@rtbrick.com">sales@rtbrick.com</a>

©Copyright 2020 RtBrick, Inc. All rights reserved. The information contained herein is subject to change without notice. The trademarks, logos and service marks ("Marks") displayed in this documentation are the property of RtBrick in the United States and other countries. Use of the Marks are subject to RtBrick's Term of Use Policy, available at <https://www.rtbrick.com/privacy>. Use of marks belonging to other parties is for informational purposes only.

# Table of Contents

1. Introduction to Forwarding . . . . .	3
2. Interface Commands . . . . .	4
2.1. Display All Physical Interfaces . . . . .	4
2.2. Display All Logical Interfaces . . . . .	4
2.3. Create a Logical Interface on an Instance . . . . .	5
2.4. Delete a Logical Interface . . . . .	6
2.5. Show Interface Addresses . . . . .	7
2.6. Assign Logical Interface IPv4 Address . . . . .	7
2.7. Assign Logical Interface IPv6 Address . . . . .	8
2.8. Delete Logical Interface IPv4 Address . . . . .	9
2.9. Delete Logical Interface IPv6 Address . . . . .	10
2.10. Disable (Shut Down) a Logical Interface . . . . .	11
2.11. Enable a Logical Interface . . . . .	12
2.12. Disable IPv4 on a Logical Interface . . . . .	12
2.13. Disable IPv6 on a Logical Interface . . . . .	13
2.14. Enable IPv4 on a Logical Interface . . . . .	14
2.15. Enable IPv6 on a Logical Interface . . . . .	15
2.16. Set IPv4 or IPv6 MTU Size . . . . .	16
2.17. Display the IPv4 Unicast Routing Table . . . . .	17
2.18. Display the IPv4 Unicast Routing Table Detail . . . . .	18
2.19. Display the IPv6 Unicast Routing Table . . . . .	18
2.20. Display the IPv4 Unicast Routing Table for a VRF Instance . . . . .	19
2.21. Display the Details of IPv4 Unicast Routing Table for a VRF Instance . . . . .	19
2.22. Display the IPv6 Unicast Routing Table for a VRF Instance . . . . .	20
2.23. Display the IPv6 Labeled-Unicast Routing Table for the mgmt Instance . . . . .	21
2.24. Display the IPv4 Unicast Routing Table for the mgmt Instance . . . . .	21
2.25. Display the IPv6 Unicast Routing Table for the mgmt Instance . . . . .	22
2.26. Display the MPLS Routing Table . . . . .	22
2.27. Ping an IPv4 Address That is Part of a VRF Instance . . . . .	23
2.28. Ping an IPv6 Address That is Part of a VRF Instance . . . . .	23

# 1. Introduction to Forwarding

FWDD interface commands fall into four major areas:

- Physical interface commands
- Logical interface commands
- MTU size command
- Routing table (IPv4, IPv6, VRF, MPLS) commands

## 2. Interface Commands

### 2.1. Display All Physical Interfaces

Command to display the status, MAC addresses, and bandwidth of all physical interfaces

**rtb ifmd show interface physical**

physical	Show physical interface
----------	-------------------------

#### Example

```
ubuntu@spine1:~$ rtb ifmd show interface physical
+-----+-----+-----+-----+
+-----+
Interface Admin Status Link Status Oper Status MAC Address UpTime
+-----+-----+-----+-----+
+-----+
lo-1/2/1 up up up 7a:d8:e6:69:00:02 Wed
Mar 18 11:03:05 GMT +0000 2020
lo-2/2/1 up up up 7a:d8:e6:69:00:03 Wed
Mar 18 11:03:05 GMT +0000 2020
memif-1/2/1 up up up 7a:d8:e6:69:00:01 Wed
Mar 18 11:03:15 GMT +0000 2020
```

### 2.2. Display All Logical Interfaces

Command to display the status, MTU size, and other information about all logical interfaces

**rtb ifmd show interface logical**

logical	Show logical interface
---------	------------------------

#### Example

```
ubuntu@spine1:~$ rtb ifmd show interface logical
+-----+-----+-----+-----+-----+
+-----+-----+
 Interface      Admin Status Link Status  Oper Status Outer Vlan Inner Vlan MAC
Address        Instance
+-----+-----+-----+-----+-----+
+-----+-----+
 lo-1/2/1/1     up       up       up
7a:d8:e6:69:00:02 default
 lo-2/2/1/2     up       up       up
7a:d8:e6:69:00:03 default
 memif-1/2/1/1   up       up       up
7a:d8:e6:69:00:01 default
+-----+-----+-----+-----+
+-----+-----+
```

## 2.3. Create a Logical Interface on an Instance

The following command creates an interface on the default instance.

**rtb confd set interface physical <physical interface> logical unit <logical-unit-id>**

<physical interface>	Physical interface name
<logical-unit>	Logical unit ID

### Example

```
ubuntu@s1:~$ rtb confd set interface physical lo-0/0/0 logical unit 1
ubuntu@s1:~$
ubuntu@s1:~$ rtb ifmd show interface logical
+-----+-----+-----+-----+-----+
+-----+-----+
 Interface      Admin Status Link Status  Oper Status Outer Vlan Inner Vlan MAC
Address        Instance
+-----+-----+-----+-----+-----+
+-----+-----+
 lo-0/0/0/1     up       up       up
7a:2d:63:d1:00:01 default
 lo-0/0/0/4     up       up       up
7a:2d:63:d1:00:01 default
+-----+-----+-----+-----+
+-----+-----+
```

The following command creates an interface on the specified instance.

**rtb confd set interface physical <physical interface> logical unit <logical-unit-id> instance <instance Name>**

<physical interface>	Physical interface name
----------------------	-------------------------

<logical-unit>	Logical unit ID
<instance name>	Instance name

## Example

```
ubuntu@s1:~$ rtb confd set interface physical lo-0/0/0 logical unit 2 instance red
ubuntu@s1:~$ rtb ifmd show interface logical
+-----+-----+-----+-----+
+-----+
| Interface      Admin Status Link Status  Oper Status  Outer Vlan Inner Vlan MAC
| Address        Instance
+-----+-----+-----+-----+
+-----+-----+
| lo-0/0/0/1     up       up       up
| 7a:2d:63:d1:00:01 default
| lo-0/0/0/2     up       up       up
| 7a:2d:63:d1:00:01 red
| lo-0/0/0/4     up       up       up
| 7a:2d:63:d1:00:01 default
+-----+-----+-----+-----+
+-----+-----+
```

## 2.4. Delete a Logical Interface

Command to delete logical interface in instance (a show command will verify deletion)

**rtb confd delete interface physical <physical interface> logical unit <logical-unit-id>**

<physical interface>	Physical interface name
<logical-unit>	Logical unit ID

## Example

```
ubuntu@spine1:~$ rtb confd delete interface physical lo-1/2/1 logical unit 1
ubuntu@spine1:~$ rtb ifmd show interface logical
+-----+-----+-----+-----+
+-----+
| Interface      Admin Status Link Status  Oper Status  Outer Vlan Inner Vlan MAC
| Address        Instance
+-----+-----+-----+-----+
+-----+-----+
| lo-2/2/1/2     up       up       up
| 7a:d8:e6:69:00:03 default
| memif-1/2/1/1   up       up       up
| 7a:d8:e6:69:00:01 default
+-----+-----+-----+-----+
+-----+-----+
```

## 2.5. Show Interface Addresses

Command to display the IPv4 and IPv6 addresses used on interfaces

**rtb ifmd show interface address**

address	Interface address
---------	-------------------

### Example

```
ubuntu@spine1:~$ rtb ifmd show interface address
+-----+-----+-----+
+-----+-----+
| Interface | Instance | IPv4 | Primary | IPv6 |
+-----+-----+-----+
+-----+
| lo-1/2/1/1 | default | 1.1.1.1/32 | true |
+-----+
+-----+
| lo-2/2/1/2 | default | 4.4.4.4/32 | true |
+-----+
+-----+
| memif-1/2/1/1 | default | 10.1.1.1/24 | true |
| memif-1/2/1/1 | default | | true |
fe80::78d8:e6ff:fe69:1/128
+-----+-----+-----+
```

## 2.6. Assign Logical Interface IPv4 Address

Command to assign an IPv4 address to a logical interface on the default instance and verify that the assignment is correct

**rtb confd set interface physical <physical interface> logical unit <logical-unit-id> address ipv4 <ipv4-address>**

<physical interface>	Physical interface to act on
<logical unit>	Logical Unit ID
<ipv4-address>	IPv4 address to assign

### Example

```
ubuntu@spine1:~$ rtb confd set interface physical lo-1/2/1 logical unit 1 address ipv4
1.1.1.1/32
ubuntu@spine1:~$ rtb ifmd show interface address
+-----+-----+-----+
+-----+
| Interface | Instance | IPv4 | Primary | IPv6 |
+-----+-----+-----+-----+
+-----+
| lo-1/2/1/1 | default | 1.1.1.1/32 | true |
+-----+
+-----+
| lo-2/2/1/2 | default | 4.4.4.4/32 | true |
+-----+
+-----+
| memif-1/2/1/1 | default | 10.1.1.1/24 | true |
| memif-1/2/1/1 | default | | true |
fe80::78d8:e6ff:fe69:1/128
+-----+-----+-----+
+-----+
```

## 2.7. Assign Logical Interface IPv6 Address

Command to assign an IPv6 address (as primary) to a logical interface on the default instance and verify that the assignment is correct

**rtb confd set interface physical <physical interface> logical unit <logical-unit-id> address ipv6 <ipv6-address>**

<physical interface>	Physical interface to act on
<logical unit>	Logical Unit ID
<ipv6-address>	IPv6 address to assign

### Example

```
ubuntu@spine1:~$ rtb confd set interface physical lo-1/2/1 logical unit 1 address ipv6
10:1:1::1/128
ubuntu@spine1:~$ rtb ifmd show interface address
+-----+-----+-----+
+-----+-----+-----+
| Interface | Instance | IPv4 | Primary | IPv6 |
+-----+-----+-----+-----+
+-----+
| lo-1/2/1/1 | default | 1.1.1.1/32 | true | 10:1:1::1/128 |
+-----+
+-----+
| lo-2/2/1/2 | default | 4.4.4.4/32 | true |  |
+-----+
+-----+
| memif-1/2/1/1 | default | 10.1.1.1/24 | true |  |
| memif-1/2/1/1 | default |  | true |  |
fe80::78d8:e6ff:fe69:1/128
+-----+-----+-----+
+-----+
```

## 2.8. Delete Logical Interface IPv4 Address

Command to delete the IPv4 address of a logical interface (without deleting the logical interface itself)

**rtb confd delete interface physical <physical interface> logical unit <logical-unit-id> address ipv4 <ipv4-address>**

<physical interface>	Physical interface to act on
<logical unit>	Logical Unit ID
<ipv4-address>	IPv6 address

### Example

```

ubuntu@s1:~$ rtb confd set interface physical lo-0/0/0 logical unit 4 address ipv4
4.4.4.4/32
ubuntu@s1:~$
ubuntu@s1:~$ rtb ifmd show interface address
+-----+-----+-----+
+-----+-----+-----+
| Interface | Instance | IPv4 | Primary | IPv6 |
+-----+-----+-----+-----+
+-----+-----+-----+
| lo-0/0/0/4 | default | 4.4.4.4/32 | true |
+-----+-----+-----+
+-----+
ubuntu@s1:~$
ubuntu@s1:~$ rtb confd delete interface physical lo-0/0/0 logical unit 4 address ipv4
4.4.4.4/32
ubuntu@s1:~$
ubuntu@s1:~$ rtb ifmd show interface address
ubuntu@s1:~$
ubuntu@s1:~$
```

## 2.9. Delete Logical Interface IPv6 Address

Command to delete the IPv6 address of a logical interface (without deleting the logical interface itself)

**rtb confd delete interface physical <physical interface> logical unit <logical-unit-id> address ipv6 <ipv6-address>**

<physical interface>	Physical interface to act on
<logical unit>	Logical Unit ID
<ipv6-address>	IPv6 address

### Example

```

ubuntu@s1:~$ rtb confd set interface physical lo-0/0/0 logical unit 4 address ipv6
4::4/128
ubuntu@s1:~$
ubuntu@s1:~$ rtb ifmd show interface address
+-----+-----+-----+
+-----+-----+-----+
| Interface | Instance | IPv4 | Primary | IPv6 |
+-----+-----+-----+-----+
| lo-0/0/0/4 | default |      | true    | 4::4/128 |
+-----+-----+-----+
+-----+
ubuntu@s1:~$
ubuntu@s1:~$ rtb confd delete interface physical lo-0/0/0 logical unit 4 address ipv6
4::4/128
ubuntu@s1:~$
ubuntu@s1:~$ rtb ifmd show interface address
ubuntu@s1:~$
ubuntu@s1:~$
```

## 2.10. Disable (Shut Down) a Logical Interface

Command to disable (shut down) a logical interface on the default instance

**rtb confd set interface physical <physical interface> logical unit <logical-unit-id> disable**

<physical interface>	Physical interface name
<logical-unit-id>	Logical unit ID

### Example

```

ubuntu@spine1:~$ rtb confd set interface physical lo-1/2/1 logical unit 1 disable
ubuntu@spine1:~$ rtb ifmd show interface logical
+-----+-----+-----+-----+-----+
+-----+-----+-----+-----+
| Interface | Admin Status | Link Status | Oper Status | Outer Vlan | Inner Vlan | MAC |
| Address   | Instance     |             |             |            |            |       |
+-----+-----+-----+-----+-----+
| lo-1/2/1/1 | up          | up          | down        |            |            |       |
7a:d8:e6:69:00:02 | default     |             |             |            |            |       |
| lo-2/2/1/2  | up          | up          | up          |            |            |       |
7a:d8:e6:69:00:03 | default     |             |             |            |            |       |
| memif-1/2/1/1| up          | up          | up          |            |            |       |
7a:d8:e6:69:00:01 | default     |             |             |            |            |       |
+-----+-----+-----+-----+-----+
+-----+-----+
```

## 2.11. Enable a Logical Interface

Command to enable a logical interface that was previously shut down (essentially, delete the disable sent to the interface)

**rtb confd delete interface physical <physical interface> logical unit <logical-unit-id> disable**

<physical interface>	Physical interface name
<logical-unit-id>	Logical Unit ID

### Example

```
ubuntu@spine1:~$ rtb confd delete interface physical lo-1/2/1 logical unit 1 disable
ubuntu@spine1:~$ rtb ifmd show interface logical
+-----+-----+-----+-----+
+-----+-----+
Interface          Admin Status Link Status  Oper Status Outer Vlan Inner Vlan MAC
Address           Instance
+-----+-----+-----+-----+-----+
+-----+-----+
lo-1/2/1/1        up      up      up
7a:d8:e6:69:00:02 default
lo-2/2/1/2        up      up      up
7a:d8:e6:69:00:03 default
memif-1/2/1/1     up      up      up
7a:d8:e6:69:00:01 default
+-----+-----+-----+-----+
+-----+-----+
```

## 2.12. Disable IPv4 on a Logical Interface

Command to disable IPv4 on a logical interface on the default instance

**rtb confd set interface physical <physical interface> logical unit <logical-unit-id> ipv4-disable**

<physical interface>	Physical interface name
<logical-unit-id>	Logical Unit ID

### Example

```

ubuntu@spine1:~$ rtb confd set interface physical lo-1/2/1 logical unit 1 ipv4-disable
ubuntu@spine1:~$ rtb ifmd show interface logical lo-1/2/1/1
Logical Interface Name    lo-1/2/1/1
  Interface Index          2597
  Physical Interface Name  lo-1/2/1
  Logical Unit Id          1
  Admin Status              up
  Link Status               up
  Oper Status               up
  Ifl Type                 Loopback interface
  MAC                       7a:d8:e6:69:00:02
  Instance                  default
Address-family:
  IPv4:
    Status      Down
  IPv6:
    Status      up
  MPLS
    Status      up

  Counter          Count
  drops            :403
  ip6              :403
  tx bytes         :69916
  tx packets       :806
+-----+-----+
  IPv4           primary flag IPv6
+-----+-----+
  1.1.1.1/32     true
                  true        10:1:1::1/128

```

## 2.13. Disable IPv6 on a Logical Interface

Command to disable IPv6 on a logical interface on the default instance

**rtb confd set interface physical <physical interface> logical unit <logical-unit-id> ipv6-disable**

<physical interface>	Physical interface name
<logical-unit-id>	Logical Unit ID

### Example

```

ubuntu@spine1:~$ rtb confd set interface physical lo-1/2/1 logical unit 1 ipv6-disable
ubuntu@spine1:~$ rtb ifmd show interface logical lo-1/2/1/1
Logical Interface Name    lo-1/2/1/1
  Interface Index          2597
  Physical Interface Name  lo-1/2/1
  Logical Unit Id          1
  Admin Status              up
  Link Status               up
  Oper Status               up
  Ifl Type                 Loopback interface
  MAC                       7a:d8:e6:69:00:02
  Instance                  default
Address-family:
  IPv4:
    Status      up
  IPv6:
    Status      Down
  MPLS
    Status      up

  Counter          Count
  drops            :403
  ip6              :403
  tx bytes         :69916
  tx packets       :806
+-----+-----+
  IPv4           primary flag IPv6
+-----+-----+
  1.1.1.1/32     true
                  true          10:1:1::1/128

```

## 2.14. Enable IPv4 on a Logical Interface

Command to enable IPv4 on a logical interface that was previously shut down (essentially, delete the disable sent to the interface)

**rtb confd delete interface physical <physical interface> logical unit <logical-unit-id> ipv4-disable**

<physical interface>	Physical interface name
<logical-unit-id>	Logical Unit ID

### Example

```

ubuntu@spine1:~$ rtb confd delete interface physical lo-1/2/1 logical unit 1 ipv4-
disable
ubuntu@spine1:~$ rtb ifmd show interface logical lo-1/2/1/1
Logical Interface Name    lo-1/2/1/1
  Interface Index          2597
  Physical Interface Name lo-1/2/1
  Logical Unit Id          1
  Admin Status              up
  Link Status               up
  Oper Status               up
  Ifl Type                 Loopback interface
  MAC                       7a:d8:e6:69:00:02
  Instance                  default
Address-family:
  IPv4:
    Status      up
  IPv6:
    Status      up
  MPLS
    Status      up

  Counter          Count
  drops            :403
  ip6              :403
  tx bytes         :69916
  tx packets       :806
+-----+-----+
  IPv4           primary flag IPv6
+-----+-----+
  1.1.1.1/32     true
                  true          10:1:1::1/128

```

## 2.15. Enable IPv6 on a Logical Interface

Command to enable IPv6 on a logical interface that was previously shut down (essentially, delete the disable sent to the interface)

**rtb confd delete interface physical <physical interface> logical unit <logical-unit-id> ipv6-disable**

<physical interface>	Physical interface name
<logical-unit-id>	Logical Unit ID

### Example

```

ubuntu@spine1:~$ rtb confd delete interface physical lo-1/2/1 logical unit 1 ipv6-
disable
ubuntu@spine1:~$ rtb ifmd show interface logical lo-1/2/1/1
Logical Interface Name    lo-1/2/1/1
  Interface Index          2597
  Physical Interface Name lo-1/2/1
  Logical Unit Id          1
  Admin Status              up
  Link Status               up
  Oper Status               up
  Ifl Type                 Loopback interface
  MAC                       7a:d8:e6:69:00:02
  Instance                  default
Address-family:
  IPv4:
    Status      up
  IPv6:
    Status      up
  MPLS
    Status      up

  Counter          Count
  drops            :403
  ip6              :403
  tx bytes         :69916
  tx packets       :806
+-----+-----+
  IPv4           primary flag IPv6
+-----+-----+
  1.1.1.1/32     true
                  true          10:1:1::1/128

```

## 2.16. Set IPv4 or IPv6 MTU Size

Command to assign an IPv4 or IPv6 MTU size to a logical interface

**rtb confd set interface physical <physical interface> logical unit <logical-unit-id> <ipv4-mtu | ipv6-mtu> <mtu-size>**

<physical interface>	Physical interface name
<logical-unit-id>	Logical Unit ID
<ipv4-mtu   ipv6-mtu>	
Set MTU for IPv4 or IPv6	<mtu-size>

### Example

```

ubuntu@spine1:~$ rtb confd set interface physical lo-1/2/1 logical unit 1 ipv4-mtu 299
ubuntu@spine1:~$ rtb ifmd show interface logical lo-1/2/1/1
Logical Interface Name    lo-1/2/1/1
  Interface Index          2597
  Physical Interface Name lo-1/2/1
  Logical Unit Id         1
  Admin Status             up
  Link Status              up
  Oper Status              up
  Ifl Type                Loopback interface
  MAC                      7a:70:97:a8:00:02
  Instance                default
Address-family:
  IPv4:
    Status      up
    ipv4_mtu   299
  IPv6:
    Status      up
  MPLS
    Status      up

  Counter          Count
  drops            :86
  ip6              :86
  tx bytes        :14880
  tx packets      :172
+-----+-----+
  IPv4           primary flag IPv6
+-----+-----+
  1.1.1.1/32     true

```

## 2.17. Display the IPv4 Unicast Routing Table

Command to display the prefix, source, preference, and next-hop for IPv4 unicast routes for the default instance

**rtb fibd show ipv4 route unicast**

unicast	Routing table to display
---------	--------------------------

### Example

```
ubuntu@spine1:~$ rtb fibd show ipv4 route unicast
Source codes: L local, D direct, S static, BGP-LO bgp-local-origin, BGP-L bgp-local,
A-ND arp-nd,
+-----+-----+-----+
+-----+
Prefix          Source Pref Next-Hop           Egress
Interface
+-----+-----+-----+
+-----+
10.1.1.1/32      D      0 10.1.1.1
10.1.1.2/32      A-ND   6 10.1.1.2
10.1.1.0/24      D      0 10.1.1.0
1.1.1.1/32       D      0 1.1.1.1
4.4.4.4/32       D      0 4.4.4.4
0.0.0.0/0        BGP-LO 20 2.2.2.2
3.3.3.3/32       S      2 10.1.1.2
2.2.2.2/32       S      2 10.1.1.2
3.3.3.33/32     BGP-LO 20 2.2.2.2
                                         memif-1/2/1/1
                                         memif-1/2/1/1
                                         memif-1/2/1/1
                                         lo-1/2/1/1
                                         lo-2/2/1/2
                                         memif-1/2/1/1
                                         memif-1/2/1/1
                                         memif-1/2/1/1
                                         memif-1/2/1/1
```

## 2.18. Display the IPv4 Unicast Routing Table Detail

Command to display the details of IPv4 unicast routing table

**rtb fibd show ipv4 route unicast detail**

unicast	Routing table to display
---------	--------------------------

### Example

```
ubuntu@s1:~$ rtb fibd show ipv4 route unicast detail
192.1.0.1/32
Source: direct, Preference: 0
Adjacency-Hash:59c0b341d1d8bd991c8beb7dc5711aa63c2a52339e8b8a04
NextHop: 192.1.0.1
-Hash: 05d99c0a905c17df95ceefa88714f0efb04a91a435c5cf93
NextHop Type: local, NextHop Action: trap to cpu
Destination:default-ipv4-unicast
Resolved in:default-ipv4-unicast
Egress-Interface: lo-0/0/0/1
Created: Fri Mar 20 07:07:55 GMT +0000 2020
```

## 2.19. Display the IPv6 Unicast Routing Table

Command to display the prefix, source, preference, and next-hop for IPv6 unicast routes for the default instance

**rtb fibd show ipv6 route unicast**

unicast	Routing table to display
---------	--------------------------

## Example

```
ubuntu@spine1:~$ rtb fibd show ipv6 route unicast
Source codes: L local, D direct, S static, BGP-LO bgp-local-origin, BGP-L bgp-local,
               A-ND arp-nd,
+-----+-----+-----+
+-----+-----+-----+
 Prefix                  Source Pref Next-Hop
Egress Interface
+-----+-----+-----+
+-----+-----+-----+
 ::/0                     BGP-LO    20  2.2.2.2
memif-1/2/1/1
10:1:1::1/128           D          0 10:1:1::1
lo-1/2/1/1
10:1:1::2/128           ISIS       15
```

## 2.20. Display the IPv4 Unicast Routing Table for a VRF Instance

Command to display the prefix, source, preference, and next-hop for IPv4 unicast routes for the subscriber instance

**rtb fibd show ipv4 route unicast instance <instance-name>**

<instance-name>	Name of the instance (for example, subscriber)
-----------------	--

## Example

```
ubuntu@spine1:~$ rtb fibd show ipv4 route unicast instance subscriber
Source codes: L local, D direct, S static, BGP-LO bgp-local-origin, BGP-L bgp-local,
               A-ND arp-nd,
+-----+-----+-----+
+-----+-----+-----+
 Prefix                  Source Pref Next-Hop
Interface
+-----+-----+-----+
+-----+-----+-----+
 10.1.1.1/32            D          0 10.1.1.1
 10.1.1.0/24            D          0 10.1.1.0
 1.1.1.1/32             D          0 1.1.1.1
 2.2.2.2/32              ISIS      15 10.1.1.2
 10.1.1.2/32            A-ND      6 10.1.1.2
                                         Egress
                                         memif-1/2/1/1
                                         memif-1/2/1/1
                                         lo-1/2/1/1
                                         memif-1/2/1/1
                                         memif-1/2/1/1
```

## 2.21. Display the Details of IPv4 Unicast Routing Table for a VRF Instance

Command to display the details of IPv4 unicast routing table for a VRF instance

**rtb fibd show ipv4 route unicast instance <instance-name> detail**

<instance-name>	Name of the instance (for example, subscriber)
<detail>	Provides the details of the Pv4 Unicast Routing Table for a VRF Instance

## Example

```
ubuntu@s1:~$ rtb fibd show ipv4 route unicast instance mgmt-vrf detail
192.1.1.1/32
Source: direct, Preference: 0
Adjacency-Hash:2740c7e4365dcbe9cdc6b29b3a6bf7197f5fa22a432935c1
NextHop: 192.1.1.1
-Hash: 57ae1d8ab84a56ca17895e1b42963af7c830c11d7b4c9061
NextHop Type: local, NextHop Action: trap to cpu
Destination:mgmt-vrf-ipv4-unicast
Resolved in:mgmt-vrf-ipv4-unicast
Egress-Interface: lo-0/0/1/1
Created: Fri Mar 20 03:30:14 GMT +0000 2020
```

## 2.22. Display the IPv6 Unicast Routing Table for a VRF Instance

Command to display the prefix, source, preference, and next-hop for IPv6 unicast routes for the subscriber instance.

**rtb fibd show ipv6 route unicast instance <instance-name>**

<instance-name>	Name of the instance (for example, subscriber)
-----------------	--

## Example

```
ubuntu@spine2:~$ rtb fibd show ipv6 route unicast instance subscriber
Source codes: L local, D direct, S static, BGP-LO bgp-local-origin, BGP-L bgp-local,
               A-ND arp-nd,
+-----+-----+
+-----+-----+
 Prefix          Source Pref Next-Hop
 Egress Interface
+-----+-----+
+-----+-----+
 10:1::/128      A-ND      6 10:1::
memif-2/1/1/1
 10:1::1:1/128    ISIS      15 fe80::7830:dbff:fe52:1
memif-2/1/1/1
```

## 2.23. Display the IPv6 Labeled-Unicast Routing Table for the mgmt Instance

Command to display the prefix, source, preference, and next-hop for IPv6 labeled-unicast routes for the subscriber instance

**rtb fibd show ipv6 route labeled-unicast instance <instance-name>**

<instance-name>	Name of the instance (for example, mgmt)
-----------------	--

### Example

```
ubuntu@rtbrick:~$ rtb fibd show ipv6 route labeled-unicast instance default
Source codes: L local, D direct, S static, BGP-LO bgp-local-origin, BGP-L bgp-local,
A-ND arp-nd,
+-----+-----+-----+
+-----+-----+
Prefix                               Source Pref Next-Hop
Egress Interface
+-----+-----+-----+
+-----+-----+
192:1::3/128                         D          0 192:1::3
lo-0/0/0/0
192:1::1/128                         BGP-LO   200 fe80::82a2:35ff:feef:2806
ifl-0/0/26/0
ubuntu@rtbrick:~$
```

## 2.24. Display the IPv4 Unicast Routing Table for the mgmt Instance

Command to display the prefix, source, preference, and next-hop for IPv4 unicast routes for the mgmt instance

**rtb fibd show ipv4 route unicast instance <instance-name>**

<instance-name>	Name of the instance (for example, mgmt)
-----------------	--

### Example

```
ubuntu@spine1:~$ rtb fibd show ipv4 route unicast instance mgmt
Source codes: L local, D direct, S static, BGP-LO bgp-local-origin, BGP-L bgp-local,
              A-ND arp-nd,
+-----+-----+-----+
+-----+-----+
Prefix           Source Pref Next-Hop          Egress
Interface
+-----+-----+-----+
+-----+
10.1.1.1/32      D       0 10.1.1.1          memif-1/2/1/1
10.1.1.0/24      D       0 10.1.1.0          memif-1/2/1/1
1.1.1.1/32       D       0 1.1.1.1          lo-1/2/1/1
2.2.2.2/32       ISIS     15 10.1.1.2         memif-1/2/1/1
10.1.1.2/32      A-ND    6 10.1.1.2         memif-1/2/1/1
```

## 2.25. Display the IPv6 Unicast Routing Table for the mgmt Instance

Command to display the prefix, source, preference, and next-hop for IPv6 unicast routes for the mgmt instance

**rtb fibd show ipv6 route unicast instance <instance-name>**

<instance-name>	Name of the instance (for example, mgmt)
-----------------	--

### Example

```
ubuntu@spine2:~$ rtb fibd show ipv6 route unicast instance mgmt
Source codes: L local, D direct, S static, BGP-LO bgp-local-origin, BGP-L bgp-local,
              A-ND arp-nd,
+-----+-----+-----+
+-----+-----+
Prefix           Source Pref Next-Hop
Egress Interface
+-----+-----+-----+
+-----+
10:1::/128        A-ND    6 10:1::          memif-2/1/1/1
memif-2/1/1/1
10:1::1:1/128     ISIS     15 fe80::7830:dbff:fe52:1
memif-2/1/1/1
```

## 2.26. Display the MPLS Routing Table

Command to display the label, source, and next-hop for MPLS routes for the default instance

**rtb fibd show mpls route**

### Example

```
ubuntu@rtbrick:~$ rtb fibd show mpls route unicast
Source codes: L local, D direct, S static, BGP-LO bgp-local-origin, BGP-L bgp-local,
               A-ND arp-nd,
+-----+-----+-----+
+-----+
Label           Source Pref Next-Hop          Egress
Interface
+-----+-----+-----+
+-----+
label:1001      BGP    170 192:1::1
label:2001      BGP    170 fe80::82a2:35ff:feef:2806 ifl-0/0/26/0
label:20017,bos:1 BGP    170 192:1::1 ifl-0/0/26/0
label:20018,bos:1 BGP    170 192:1::1 ifl-0/0/26/0
label:20019,bos:1 BGP    170 192:1::1 ifl-0/0/26/0
label:20020,bos:1 BGP    170 fe80::82a2:35ff:feef:2806 ifl-0/0/26/0
label:20021,bos:1 BGP    170 fe80::82a2:35ff:feef:2806 ifl-0/0/26/0
label:20022,bos:1 BGP    170 fe80::82a2:35ff:feef:2806 ifl-0/0/26/0
label:20023,bos:1 BGP    170 fe80::82a2:35ff:feef:2806 ifl-0/0/26/0
label:20016,bos:1 BGP    170 192:1::1 ifl-0/0/26/0
label:20008,bos:1 BGP    170 NA
ubuntu@rtbrick:~$
```

## 2.27. Ping an IPv4 Address That is Part of a VRF Instance

Command to ping the IPv6 address used in the subscriber instance

**rtb fibd ping6 <ipv6-address> instance <instance-name>**

<ipv6-address>	Address to ping
<instance-name>	Name of instance to act on (for example, subscriber)

### Example

```
ubuntu@spine1:~$ rtb fibd ping 10.1.1.2 instance subscriber
116 bytes from 10.1.1.2: icmp_seq=1 ttl=64 time=27.7584 ms
116 bytes from 10.1.1.2: icmp_seq=2 ttl=64 time=28.0524 ms
116 bytes from 10.1.1.2: icmp_seq=3 ttl=64 time=20.0368 ms
116 bytes from 10.1.1.2: icmp_seq=4 ttl=64 time=28.0195 ms
116 bytes from 10.1.1.2: icmp_seq=5 ttl=64 time=32.0229 ms

Statistics: 5 sent, 5 received, 0% packet loss
```

## 2.28. Ping an IPv6 Address That is Part of a VRF Instance

Command to ping the IPv6 address used in the subscriber instance

**rtb fibd ping6 <ipv6-address> instance <instance-name>**

<ipv6-address>	Address to ping
<instance-name>	Name of instance to act on (for example, subscriber)

## Example

```
ubuntu@spine1:~$ rtb fibd ping6 10:1:1::1 instance subscriber
76 bytes from 10:1:1::1: icmp_seq=1 ttl=63 time=27.7891 ms
76 bytes from 10:1:1::1: icmp_seq=2 ttl=63 time=31.7864 ms
76 bytes from 10:1:1::1: icmp_seq=3 ttl=63 time=31.7316 ms
76 bytes from 10:1:1::1: icmp_seq=4 ttl=63 time=15.7478 ms
76 bytes from 10:1:1::1: icmp_seq=5 ttl=63 time=15.8116 ms

Statistics: 5 sent, 5 received, 0% packet loss
```