

Managing Software Images

Version 21.3.1, 14 April 2021

Registered Address	Support	Sales
26, Kingston Terrace, Princeton, New Jersey 08540, United States		
		+91 80 4850 5445
http://www.rtbrick.com	support@rtbrick.com	sales@rtbrick.com

©Copyright 2021 RtBrick, Inc. All rights reserved. The information contained herein is subject to change without notice. The trademarks, logos and service marks ("Marks") displayed in this documentation are the property of RtBrick in the United States and other countries. Use of the Marks are subject to RtBrick's Term of Use Policy, available at https://www.rtbrick.com/privacy. Use of marks belonging to other parties is for informational purposes only.

Table of Contents

1. Managing Software Images	3
1.1. Viewing all registered images	3
1.1.1. Viewing image details	4
1.1.2. Updating image metadata	5
1.2. Image Lifecycle Management	6

1. Managing Software Images

RBMS manages a list of software images that are currently installed on the switches in the network or eligible for being installed. The image lifecycle encompasses the following states:

- **NEW**, a new image that has been uploaded to RBMS but is not yet eligible for deployment. Typcially the integrity of a new image needs to be verified before it becomes eligible for deployment.
- **CANDIDATE**, a candidate image is eligible for deployment. It is a candidate to become the new release image if it passes all tests in the network.
- RELEASE, the release image gets installed by default.
- **SUPERSEDED**, a superseded image is a former release image which has been replaced by a newer release.
- **REVOKED**, a revoked image must not be installed on switches in the network.

Superseded and revoked images are kept in the resource inventory for the sake of documentation and to track on how many switches superseded or revoked images are installed.

The **rtb-image** tool provides an option to register new image in RBMS. The new image can be installed on a switch via Zero-Touch Provisioning (ZTP).

1.1. Viewing all registered images

To view all registered images

• Click the **Images** tab. The **Images** page appears, showing the list of registered images.

Images Manage software ima Images Inventory Met	ges Irics Jobs Administration					k 1	
Images – Images Releases	Images Explore available images Filter Enter a filter expression Search for images by adding a regular expression to filt	ter for image na	me, eleme	Filt ent role or	er platform name. Show advanced filtering options		
	Images Name	State	Туре	Chipset	Version	Roles	Element
	leer	CANDIDATE	LXC	105	20.5.0-g8daily.20200602165356- Bmaster.C7179e422		x
	rtbrick-onl-installer/rtbrick-onl-installer- accessleaf-qmx-20.5.0- g8daily.20200602171027+Bmaster.Ce64bd03c	NEW	onl- installer	qmx	20.5.0- g8daily.20200602171027+Bmaster.Ce64bd03c	spine accessleaf	x
	rtbrick-onl-installer/rtbrick-onl-installer- accessleaf-qmx-20.5.0- g8daily.20200603030630+Bmaster.Ce64bd03c	NEW	onl- installer	qmx	20.5.0- g8daily.20200603030630+Bmaster.Ce64bd03c	spine accessleaf	x

The **Images** page displays the following fields:

Field	Description
Name	Name of the software image
State	Indicates the image state such as New, Candidate, Release, Suspended, Revoked. For more information, see the Image Lifecycle Management section.
Туре	Type of the software image such as LXC or ONL
Chipset	Specifies the supported hardware name
Version	Version of the software image
Roles	The image is deployed on the specified element roles.
Element	Name of the registered element

1.1.1. Viewing image details

To view the details of an image

- 1. Click the **Images** tab. The list of registered images appear.
- 2. In the **Images** group box, click the name of the image that you want to view. The image details page appears.

Images		ctheick
Manage software ima	iges 🍂 🥬	TUTCK
Images Inventory Me	trics Jobs Administration	Logout
Images +	Images > Image rtbrick-onl-installer/rtbrick-onl-installer-accessleaf-qmx-20.5.0-g8daily.20200602171027+Bmaster.Ce installer image	e64bd03c onl-
	rtbrick-onl-installer/rtbrick-onl-installer-accessleaf-qmx-20.5.0-	
Image Information –	g8daily.20200602171027+Bmaster.Ce64bd03c	
Metadata	Review image metadata	
State	General Settings	
4	Image ID	
Applications	2a0131cd-0cd3-4956-92f7-dc5f2157e4aa	
Packages	Image UUID (readonly).	
Utilization	Organization	
	RtBrick	
	The organization that issued the image	
	Image Type	
	onl-installer	
	The image type (readonly)	
	Imane Name	
	rtbrick-onl-installer/rtbrick-onl-installer-accessleaf-qmx-20.5.0-g8daily.202	

This page displays the following fields:

Field	Description
Image ID	Image UUID (read-only)
Organization	The organization that issued the image
Image Type	The image type (read-only)
Image Name	The unique image name
Image Version	Image version (read-only)
Category	Optional image category
Description	Optional description of the image
Platform Chipset	The chipset this image is build for (read-only)
Element Roles	This image can be deployed on the selected element roles
Supported Platforms	The list of platforms on which the image can be installed

1.1.2. Updating image metadata

To update the metadata of an image

- 1. Click the **Images** tab. The list of registered images appear.
- 2. In the **Images** group box, click the name of the image whose metadata you want to update. The image details page appears.
- 3. On the left navigation pane, click **Metadata**.

Images		dbrick
Manage software im	nages Mages	IUIICK
Images Inventory M	letrics Jobs Logs Administration	Logout
Images +	Images > Image accessleaf_EC5916-54XK_onl-installer_20.6.0-g6daily.20200623033220+Bdevelopment.C8e4ec16 image	e0 onl-installer
	accessleaf_EC5916-54XK_onl-installer_20.6.0-	
Image Information –	g6daily.20200623033220+Bdevelopment.C8e4ec1e0	
Metadata	Review image metadata	
State	General Settings	
Applications	Image ID	
Applications	90a1715f-4c12-48b8-a234-f33dd1c1ccef	
Packages	Image UUID (readonly).	
Utilization	Organization	
	The organization that issued the image	
	Image Туре	
	onl-installer	
	The image type (readonly)	

- 4. Update image metadata such as image ID, type, name, and version.
- 5. Click Save settings.

1.2. Image Lifecycle Management

The image lifecycle defines five different image states. A new image is an image that has not yet been approved to be eligible for a deployment. The release image is deployed by default. A candidate image is intended to become the new default image, once the candidate has passed all necessary tests. The existing default image is superseded by the new default image. A revoked image must not be used any longer because it contains severe errors.

- 1. Click the **Images** tab. The list of registered images appear.
- 2. Click the name of the image that you want to view.
- 3. Click **State** in the left navigation pane.
- 4. From the following list of states, select the state that you want to apply.



Save state

- New: Newly registered image
- Candidate: Candidate for the next release image
- Release: The image to be installed by default
- **Superseded**: A former release image that has been superseded by a newer image version
- **Revoked**: The image must not be used anymore.
- 5. Click Save state.