



# OAM Support

**Version 20.8.1, 10 August 2020**

Registered Address	Support	Sales
26, Kingston Terrace, Princeton, New Jersey 08540, United States		
		+91 80 4850 5445
<a href="http://www.rtbrick.com">http://www.rtbrick.com</a>	<a href="mailto:support@rtbrick.com">support@rtbrick.com</a>	<a href="mailto:sales@rtbrick.com">sales@rtbrick.com</a>

©Copyright 2020 RtBrick, Inc. All rights reserved. The information contained herein is subject to change without notice. The trademarks, logos and service marks ("Marks") displayed in this documentation are the property of RtBrick in the United States and other countries. Use of the Marks are subject to RtBrick's Term of Use Policy, available at <https://www.rtbrick.com/privacy>. Use of marks belonging to other parties is for informational purposes only.

# Table of Contents

1. Introduction to OAM .....	3
2. Using OAM Commands .....	4
2.1. Guidelines .....	4
2.2. IP Ping .....	4
2.2.1. IP ping in default instance .....	4
2.2.2. IP ping in specific instance and afi/safi .....	5
2.3. IPv6 Ping .....	6
2.3.1. IPv6 ping in default instance .....	6
2.3.2. IPv6 ping in specific instance and afi/safi .....	7
2.4. IP traceroute .....	8
2.4.1. IP traceroute in default instance .....	8
2.4.2. IP traceroute in particular instance and afi/safi .....	9
2.5. IPv6 traceroute .....	10
2.5.1. IPv6 traceroute in default instance .....	10
2.5.2. IPv6 traceroute in particular instance and afi/safi .....	11

# 1. Introduction to OAM

Operations, Administration and Management (OAM) are the processes, activities, tools, and standards involved with performing operational, administrative, and management tasks. RBFS provides the following OAM features that enable you troubleshoot RtBrick software:

- IP ping
- IP traceroute
- IP ping on an MPLS transport
- IP traceroute on an MPLS transport

MPLS ping and traceroute will be supported in the later releases

## 2. Using OAM Commands

### 2.1. Guidelines

- Execute the OAM commands in the **rtb fibd** mode.

### 2.2. IP Ping

The IP ping utility is used to check the reachability of an IP address.

#### 2.2.1. IP ping in default instance

The **ping** command allows you to ping to a destination to see if a networked device is reachable.

##### Syntax

```
ping <destination-ip> [source <interface>] count <count> interval <interval>  
size <size> source-ip <source-ip> ttl <ttl>
```

##### Command Parameters

destination-ip	ipv4 destination address
interface	source interface
count	count of the ping packet (default 5)
interval	interval between the packets (default 1 sec)
size	size of the ping packet (default 60)
source-ip	IPv4 source address
ttl	Time-to-live to be used in the packet



All the parameters except *source <interface>* should be specified in the same order for all ping commands.

##### Command modes

```
rtb fibd
```

##### Example

```
ubuntu@vpp:~$ rtb fibd ping 30.10.1.2

116 bytes from 30.10.1.2: icmp_seq=1 ttl=64 time=18.1306 ms
116 bytes from 30.10.1.2: icmp_seq=2 ttl=64 time=32.1058 ms
116 bytes from 30.10.1.2: icmp_seq=3 ttl=64 time=19.8205 ms
116 bytes from 30.10.1.2: icmp_seq=4 ttl=64 time=20.0144 ms
116 bytes from 30.10.1.2: icmp_seq=5 ttl=64 time=32.0085 ms
Statistics: 5 sent, 5 received, 0% packet loss
```

## 2.2.2. IP ping in specific instance and afi/safi

This command allows you to ping to a destination in a particular VRF.

### Syntax

```
ping <destination-ip> [instance <instance-name> afi <afi> safi<safi>] [source <interface>] count <count> interval <interval> size <size> source-ip <source-ip> ttl <ttl>
```

### Command Parameters

destination-ip	ipv4 destination address
instance-name	instance on which ping has to be executed
afi	IPv4 Address Family Identifier (AFI)
safi	Subsequent address family identifier (SAFI)
interface	source interface
count	count of the ping packet (default 5)
interval	interval between the packets (default 1 sec)
size	size of the ping packet (default 60)
source-ip	IPv4 source address
ttl	Time-to-live to be used in the packet



The afi/safi attributes are optional; if not specified, afi would be ipv4 and safi would be unicast.

### Command modes

```
rtb fibd
```

### Example

```
ubuntu@vpp:~$ rtb fibd ping 30.10.1.2 instance abc afi ipv4 safi labeled-unicast

116 bytes from 30.10.1.2: icmp_seq=1 ttl=64 time=18.1306 ms
116 bytes from 30.10.1.2: icmp_seq=2 ttl=64 time=32.1058 ms
116 bytes from 30.10.1.2: icmp_seq=3 ttl=64 time=19.8205 ms
116 bytes from 30.10.1.2: icmp_seq=4 ttl=64 time=20.0144 ms
116 bytes from 30.10.1.2: icmp_seq=5 ttl=64 time=32.0085 ms

Statistics: 5 sent, 5 received, 0% packet loss
```

## 2.3. IPv6 Ping

The IPv6 ping utility is used to check the reachability of an IPv6 address.

### 2.3.1. IPv6 ping in default instance

The **ping6** command allows you to ping to an IPv6 destination to see if a networked device is reachable.

#### Syntax

```
ping6 <destination-ipv6> [source <interface>] count <count> interval <interval> size <size> source-ip <source-ipv6> ttl <ttl>
```

#### Command Parameters

destination-ipv6	ipv6 destination address
interface	source interface
count	count of the ping packet (default 5)
interval	interval between the packets (default 1 sec)
size	size of the ping packet (default 60)
source-ipv6	IPv6 source address
ttl	Time-to-live to be used in the packet

#### Command modes

```
rtb fibd
```

#### Example

```
ubuntu@vpp:~$ rtb fibd ping6 fec0::2556:0:1

76 bytes from fec0::2556:0:1: icmp_seq=1 ttl=64 time=.0503 ms
76 bytes from fec0::2556:0:1: icmp_seq=2 ttl=64 time=.0321 ms
76 bytes from fec0::2556:0:1: icmp_seq=3 ttl=64 time=.0314 ms
76 bytes from fec0::2556:0:1: icmp_seq=4 ttl=64 time=.0325 ms
76 bytes from fec0::2556:0:1: icmp_seq=5 ttl=64 time=.0354 ms

Statistics: 5 sent, 5 received, 0% packet loss
```

### 2.3.2. IPv6 ping in specific instance and afi/safi

This command allows you to ping to an IPv6 destination in a particular VRF.

#### Syntax

```
ping6 <destination-ipv6> [instance <instance-name> afi<afi> safi<safi>]
[source<interface>] count <count> interval <interval> size <size> source-ip
<source-ipv6> ttl <ttl>
```

#### Command Parameters

destination-ipv6	ipv6 destination address
instance-name	instance on which ping has to be executed
afi	IPv4 Address Family Identifier (AFI)
safi	Subsequent address family identifier (SAFI)
interface	source interface
count	count of the ping packet (default 5)
interval	interval between the packets (default 1 sec)
size	size of the ping packet (default 60)
source-ipv6	IPv6 source address
ttl	Time-to-live to be used in the packet



The afi/safi attributes are optional; if not specified, afi would be ipv6 and safi would be unicast.

#### Command modes

```
rtb fibd
```

#### Example

```
ubuntu@vpp:~$ rtb fibd ping6 fec0::2556:0:1 instance abc afi ipv6 safi
labeled-unicast

76 bytes from fec0::2556:0:1: icmp_seq=1 ttl=64 time=.0503 ms
76 bytes from fec0::2556:0:1: icmp_seq=2 ttl=64 time=.0321 ms
76 bytes from fec0::2556:0:1: icmp_seq=3 ttl=64 time=.0314 ms
76 bytes from fec0::2556:0:1: icmp_seq=4 ttl=64 time=.0325 ms
76 bytes from fec0::2556:0:1: icmp_seq=5 ttl=64 time=.0354 ms

Statistics: 5 sent, 5 received, 0% packet loss
```

## 2.4. IP traceroute

### 2.4.1. IP traceroute in default instance

This command allows you to traceroute to a particular IP destination.

#### Syntax

```
traceroute <destination-ip> [source <interface>] repeat <repeat> size
<pktsize> source-ip <source-ip> interval <interval> maxhop <maxhop>
```

destination-ip	ipv4 destination address
interface	source interface
repeat	no of packets for each hop (default 3)
pktsize	size of the traceroute packet (default 60)
source-ip	source IP address
interval	interval between the packets (default 1 sec)
maxhop	max number of hops before the TTL expires (default 30)



All the parameters except source <interface> should be specified in the same order for all traceroute commands.

#### Command modes

```
rtb fibd
```

#### Example

```
ubuntu@vpp:~$ rtb fibd traceroute 30.10.1.2
traceroute to 30.10.1.2, 30 hops max, 60 byte packets
1  20.10.1.2      39.401 ms       19.919 ms      20.074 ms
2  30.10.1.2      55.544 ms       36.765 ms      45.989 ms
```

## 2.4.2. IP traceroute in particular instance and afi/safi

This command allows you to traceroute to a particular IP destination in a particular VRF.

### Syntax

```
traceroute <destination-ip> [instance <instance-name> afi <afi> safi<safi>]
[source <interface>] repeat <repeat> size <pktsize> source-ip <source-ip>
interval <interval> maxhop <maxhop>
```

destination-ip	ipv4 destination address
instance-name	instance on which traceroute has to be executed
afi	IPv4 Address Family Identifier (AFI)
safi	Subsequent address family identifier (SAFI)
interface	source interface
repeat	no of packets for each hop (default 3)
pktsize	size of the traceroute packet (default 60)
source-ip	source IP address
interval	interval between the packets (default 1 sec)
maxhop	max number of hops before the TTL expires (default 30)



The afi/safi attributes are optional; if not specified, afi would be ipv4 and safi would be unicast.

### Command modes

```
rtb fibd
```

### Example

```
ubuntu@vpp:~$ rtb fibd traceroute 30.10.1.2 instance abc afi ipv4 safi
labeled-unicast

traceroute to 30.10.1.2, 30 hops max, 60 byte packets
1  20.10.1.2      39.401 ms       19.919 ms       20.074 ms
2  30.10.1.2      55.544 ms       36.765 ms       45.989 ms
```

## 2.5. IPv6 traceroute

### 2.5.1. IPv6 traceroute in default instance

This command allows you to traceroute to a particular IP destination.

#### Syntax

```
traceroute6 <destination-ipv6> [source <interface>] repeat <repeat> size
<pktsize> source-ip <source-ipv6> interval <interval> maxhop <maxhop>
```

destination-ipv6	ipv6 destination address
interface	source interface
repeat	no of packets for each hop (default 3)
pktsize	size of the traceroute packet (default 60)
source-ip	IPv6 source address
interval	interval between the packets (default 1 sec)
maxhop	max number of hops before the TTL expires (default 30)

#### Command modes

```
rtb fibd
```

#### Example

```
ubuntu@vpp:~$ rtb fibd traceroute6 fec0::3556:0:1

traceroute to fec0::3556:0:1 30 hops max, 60 byte packets
1 fec0::2556:1:1 21.247 ms 20.232 ms 20.052 ms
2 fec0::3556:0:1 50.124 ms 59.822 ms 40.032 ms
```

## 2.5.2. IPv6 traceroute in particular instance and afi/safi

This command allows you to traceroute to a particular IPv6 destination in a particular VRF.

### Syntax

```
traceroute6 <destination-ipv6> [instance <instance-name> afi<afi> safi<safi>]
[source <interface>] repeat <repeat> size <pktsize> source-ip <source-ipv6>
interval <interval> maxhop <maxhop>
```

destination-ipv6	ipv6 destination address
instance-name	instance on which traceroute has to be executed
afi	IPv4 Address Family Identifier (AFI)
safi	Subsequent address family identifier (SAFI)
interface	source interface
repeat	no of packets for each hop (default 3)
pktsize	size of the traceroute packet (default 60)
source-ip	IPv6 source address
interval	interval between the packets (default 1 sec)
maxhop	max number of hops before the TTL expires (default 30)



The afi/safi attributes are optional; if not specified, afi would be ipv6 and safi would be unicast.

### Command modes

```
rtb fibd
```

### Example

```
ubuntu@vpp:~$ rtb fibd traceroute6 fec0::3556:0:1 instance abc afi ipv4 safi
labeled-unicast

traceroute to fec0::3556:0:1 30 hops max, 60 byte packets
1 fec0::2556:1:1 21.247 ms 20.232 ms 20.052 ms
2 fec0::3556:0:1 50.124 ms 59.822 ms 40.032 ms
```